




## RF46-2 REDUCTION GEARBOX





## RF46-2 REDUCTION GEARBOX

RAVO Partslist for RF46/2 gearbox

Only frequently used PN's are mentioned in the list.

Pos number:	Ravo PN:	Description:	Qty:
1	5014364	Spindle	1
3	5014304	Wheel hub	1
5	5014292	Ring-gear	1
6	5014293	Cover	1
7	5014132	Brake drum	1
8	5014322	Coupling	1
9	4010479	Locking cap	1
10	4010478	Pin	1
11	4010475	Thrust washer	1
12	5014321	Shaft	1
13	5014390	Spring	1
14		Not used by RAVO	1
15	5014297	Coupling	1
18	5014150	Bearing	1
19	5014155	Bearing	1
20	4010457	Bearing	1
21	5014175	Bearing	1
22	5014159	Sealing	1
24	4010477	O-ring	1
25	4010476	O-ring	1
26	5014050	O-ring	1
27	5014145	O-ring	1
29	5014366	Circlip	1
30	5014389	Circlip	1
31	5014179	Circlip	1
33	5014157	Retaining ring	1
34	5014128	Retaining ring	1
36	5014147	Bearing nut	1
37	5014149	Tab washer	1
38	5014152	Spring pin	4
39	4300610	Screw	3
40	5014282	Screw	13
41	4320820	Screw	2
42	5014284	Screw	13
43	5014285	Plug 3/8	2
44	5014368	Washer	2
46	5014286	Washer	13
47	4010456	Expansion plug	1
A + B	5014289	Reduction gear, two stages	1
	5014308	Wheel bolt RF46/2	8
	5114130	Wheel nut RF46/2	8
	<b>R540-Euro3 4 5 TIER3 4</b>		
50	5014381	Brake plate left incl. shoes, springs, cyl.	1
51	5014382	Brake plate right incl. shoes, springs, cyl	1
	5014113	Brake shoes left side, set	1
	5014114	Brake shoes right side, set	1
	5075253	Brake cylinder	
	5014385	Gearbox R540, right side	1
	5014380	Gearbox R540, left side	1

Revision date: 15-3-2017